



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **SECRET WEAPON INTAKE: 304-132**

US Patent# **US 7,263,961B2**

Application : **2007 - 2008 Altima V6 3.5L**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) 3" / 1 x 1" hose 6" long
2 x 3"-3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove PCV hose from OEM intake and CCV chamber box.
 - 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
 - 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 7 Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with clamp.
 - 8 Insert Weapon*R intake pipe into the 3" side of coupler, secure with clamp.
 - 9 Measure and cut a piece of the WR 1" vacume line. Use to replace OEM PCV tube to the WR intake pipe.
 - 10 Reinstall CCV chamber to 1" WR vacume line.
 - 11 Install MAF sensor into Weapon*R intake pipe, reconect MAF sensor harness.
- Note: Secret Weapon Filter Option :**
- 12 Install the 3"- 3" coupler onto the end of the intake pipe, stretch if needed secure with supplied clamp.
 - 13 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
 - 14 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 17 Secure with washer and nut included in bracket kit.
 - 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (**If Applicable**)

