



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **SECRET WEAPON INTAKE: 304-134**

US Patent# US 7,263,961B2

Application : **2007-09 Sentra 2.0L**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter 3"](#) / 1 x 15mm x 12" Hose  
2 x 2.5"-3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 7 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 8 Insert Weapon\*R intake pipe into the 3" coupler, secure with clamp.
- 9 Measure 3" and cut a piece of the WR 15mm vacume line. Use to replace OEM pvc tube to the WR intake pipe.
- 10 Install MAF sensor into Weapon\*R intake pipe, reconect MAF sensor harness.

**Note: Secret Weapon Filter Option :**

- 11 Install the 2.5"- 3" coupler onto the end of the intake pipe, stretch if needed secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for clearance, adjust as needed for perfect fitment and clearances.  
in engine compartment. ( If Applicable )

