



Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Part # 's **Secret Weapon: 305-112**

Application : **1992-97 TOYOTA CAMRY 4CYL**

Part # 's **Secret Weapon: 305-119**

Application : **1990-95 TOYOTA MR2 NON-TURBO**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) 3" / 1 x 10mm x 12" Hose

1 x 2.5"- 3" Coupler / 1 x 3"-3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 X 10mm AIT Grommet

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the AIT sensor harness, remove AIT sensor from OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Install the 10mm AIT grommet onto the Weapon*R intake pipe, insert the AIT sensor into grommet.
- 7 Insert Weapon*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 8 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 9 Reconnect the AIT harness onto the AIT sensor.
- 10 Install the Weapon*R Hyper filter onto the end of the intake pipe.
Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
- 11 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



95 MR2 Non Turbo Dragon Intake install shown.

