



US Pat#US7,263,961B2
Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Secret Weapon Intake : 305-124**

Application : **1999-03 Lexus RX300 / 2001-04 Toyota Highlander V6**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) 3" / 1 x 10mm x 8" Hose
1 x Intake System Bracket kit / 1 x plastic "T" fitting

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3" Coupler / 2 x 3" Clamps

- 1 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 2 Remove air recirculator valve & hose from OEM intake and engine.
- 3 Remove bolts securing OEM air cleaner box, remove OEM air intake box.
- 4 **NOTE:** On highlander models disconnect the 3 x 4mm lines from the OEM airbox, and put aside.
- 5 Insert Weapon*R intake pipe into the OEM rubber intake tube, secure with clamp.
- 6 Install the 10mm hose onto the air recirculator valve and onto the Weapon*R intake pipe.
- 7 Install the Weapon*R Hyper filter onto the end of the intake pipe.
- 8 Install MAF sensor into Weapon*R intake pipe, reconnect MAF sensor harness.
- 9 **NOTE:** Highlander models use 1/4" "T" fitting and reconnect the 3 x 4mm lines from step 4, to "T" fitting (PIC BELOW)

Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.

- 8 Install the 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 9 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 10 Install U-shaped part of intake system bracket under the clamp on air filter.
- 11 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 12 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 13 Secure with washer and nut included in bracket kit.
- 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 16 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product

