



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 305-136**

US Patent# US 7,263,961B2

Application : **1997-2001 TOYOTA CAMRY V6 / 1997-1998 LEXUS ES300 V6**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) 3" / 2 x 10mm x 12" Hose
2 x 3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove PCV hoses from OEM intake and engine.
 - 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 4 Wipe the throttlebody clean of any grease, install the 3" coupler onto throttlebody, secure with OEM clamp.
 - 5 Insert Weapon*R intake pipe into the 3" coupler, secure with clamp.
 - 6 Measure the OEM PVC hose, replace with supplied 10mm hoses, install from PVC ports to intake pipe.
 - 7 Install the Weapon*R Hyper filter onto the end of the intake pipe.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 8 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 9 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
 - 10 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 11 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 12 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 13 Secure with washer and nut included in bracket kit.
 - 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 16 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

