WEAPON·R
COMPETITION PRODUCTS ®

Part # 's 305-154 (NSWP)

Application : 20005-2006 Scion TC Supercharged

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 3"-3" Coupler
1 x 2.5"-3" Reducer / 1 x Intake System Bracket kit / 4 x 3" Clamp

1 Remove bolts/ Clips securing air cleaner box, loosen clamps on rubber intake pipe.
2 Remove Silicone intake tube.
3 Disconnect the MAF sensor harness, carefully remove MAF sensor screws from OEM airbox.
4 Remove upper and lower intake box from vehicle
5 Carefully Lift MAF sensor out of top of airbox and put to the side for later installation into WR intake tube.
6 Wipe the Charger inlet clean of any grease, install the 3"-3" onto charger inlet clamp down.
7 Insert Weapon*R intake pipe into the 3" -3" coupler, secure with clamp.
8 Install MAF sensor into Weapon*R intake pipe adapter , reconnect MAF sensor harness.
   Note: Secret Weapon Filter Option :
9 Install the 2.5"3" coupler onto WR filter, secure with supplied clamp.
10 Install filter assembly onto the end of Weapon*R intake pipe, secure with clamp.
11 Install the rubber mounting grommet to the closest hole to the bracket on intake pipe.
12 Line up the bracket on the intake pipe to the rubber mounting grommet.
13 Secure with washer and nut included in bracket kit.
14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
16 Place Weapon*R CARB Sticker on a visible place in engine compartment. **(If Applicable)**

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Note: Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.