



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles

Part # 's **305-156-101 SECRET WEAPON INTAKE SYSTEM**

US Patent# US 7,263,961B2

Application : **2007-09 Scion TC**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 15mm x 24" Hose
2 x 2.5"-3" Reducer / 1 x Intake System Bracket kit / 4 x 3" Clamp**

SPECIAL NOTE: DISCONNECT NEGATIVE BATTERY CABLE BEFORE ATTEMPTING INSTALL.
DOING SO WILL RESET ECU TO ADAPT TO WEAPON-R INTAKE.

TO RESET POWER WINDOWS HOLD SWITCH IN UP POSITION FOR 10 SEC AND WINDOWS WILL RESET

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove pcv hose from OEM intake and engine valvecover, and remove OEM intake tube.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor screws from OEM airbox.
- 4 Carefully Lift MAF sensor out of top of airbox and put to the side for later installation into WR intake tube.
- 5 Wipe the throttlebody clean of any grease, install the 2.5"-3" onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon*R intake pipe into the 2.5" -3" coupler, secure with clamp.
- 7 Measure the OEM PVC hose, replace with supplied 15mm hose, install from PVC port to intake pipe.
- 8 Install the Evap Valve onto bracket located on intake tube, secure with OEM screw.
- 9 Install MAF sensor into Weapon*R intake pipe adapter , reconnect MAF sensor harness.

Note: Secret Weapon Filter Option :

- 10 Install the 2.5"3" coupler onto WR filter, secure with supplied clamp.
- 11 Install filter assembly onto the end of Weapon*R intake pipe, secure with clamp.
- 12 Install the rubber mounting grommet to the closest hole to the bracket on intake pipe.
- 13 Line up the bracket on the intake pipe to the rubber mounting grommet.
- 14 Secure with washer and nut included in bracket kit.
- 15 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 16 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 17 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Note: Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

