



CARB PENDING

Part # 's **Secret Weapon: 307-121**

Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Application : **2000-03 Ford ZX3 2.0L**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 15mm x 12" Hose / 3 x 3" coupler

1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 7 x 3" Clamp / 1 x 3" Casted elbow

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove the PCV hose from OEM intake and engine.
 - 3 Unplug and remove MAF sensor from OEM intake.
 - 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 5 Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
 - 6 Install 3" casted elbow onto 2.5"-3" coupler , install the 3" coupler onto elbow, secure with clamps.
 - 7 Insert Weapon*R intake pipe into the 3" coupler on casted elbow, secure with clamp.
 - 8 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 9 Install the hoses from their point of origin and onto the Weapon *R intake pipe.
 - 10 Install 3" coupler onto end of intake pipe, secure with clamp.
 - 11 Insert MAF into the 3" coupler, secure with clamp.
 - 12 Install the Weapon*R Hyper filter onto front of MAF.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 13 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 14 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
 - 15 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 16 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 18 Secure with washer and nut included in bracket kit.
 - 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 21 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

