



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 307-153**

US Patent# US 7,263,961B2

Application : **2003-04 Saturn ION / 2000-2003 Saturn L200 4cyl DOHC 2.2L**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 10mm x 12" Hose/ 1 x Cast aluminum elbow
1 x 2.5"- 3" Coupler / 2 x 3"-3" coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x AIT Sensor Grommet

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Disconnect and remove the PVC hose from OEM intake and engine.
- 3 Disconnect AIT sensor harness from OEM tube , remove AIT sensor from OEM tube.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Remove OEM air cleaner box on top of throttle body
- 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Install cast elbow to 3" side of coupler and clamp down
- 8 Place 3"-3" coupler over end of cast elbow and clamp down.
- 9 Insert Weapon*R intake pipe into the 3" end of the coupler, secure with clamp.
- 10 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 11 Install AIT sensor grommet onto the 15mm hole on Weapon*R intake pipe, insert AIT sensor, connect harness.
- 12 Install the hoses from their point of origin and onto the Weapon *R intake pipe.
- 13 Install the Weapon*R Hyper filter onto the end of the intake pipe.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 14 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

