



Recommend filter cleaning intervals: 3000 miles

Part # 's **Secret Weapon Intake : 307-158**

US Patent# US 7,263,961B2

Application : **95-01 LUMINA 3.1L&3.4L / 98-03 MALIBU 3.1L / 99-03 MONTE CARLO 3.4L/2000-03 3.8L**

**00-05 IMPALA 3.4&3.8L/ 94-98 ACHIEVA 3.1L/ 94-03 AURORA 4.0L/ 95-96 CIERA 3.1L**

**88-03 BONNEVILLE 3.8L / 94-97 GRAM AM 3.1L / 99-03 GRAND AM 3.4L / 97-04 GRAND PRIX 3.8L**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter](#) 3" / 1 x 10mm x 12" Hose

2 x 3 -3" Coupler / 1 x **3"-3.5" Coupler**/ 1 x Intake System Bracket kit / 1 x 3" Clamp/ 1 x Grommet

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon\*R intake pipe into the 3"-3" coupler, secure with clamp.
- 7 Vehicles with no MAF install 3"-3" coupler onto end of intake pipe, secure with clamp.
- 8 Vehicles MAF sensor install the 3"-3" coupler, secure with clamp.
- 9 Install the MAF into the 3"-3" coupler clamp down
- 10 Vehicles with AIT sensors must drill 3/4" hole in side of tube for sensor grommet. Insert AIT into grommet.
- 11 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 12 **SOME VEHICLES MAY NEED TO USE THE 3"-3.5" COUPLER ON THEIR THROTTLE BODY OR MAF SENSOR**
- 13 **MODELS WITH ECU IN OEM AIRBOX. REMOVE ECU FROM AIRBOX, IT IS OK TO LAY & SIT ECU DOWN.**
- 14 Install the 3"-3" coupler onto WR filter , secure with supplied clamp.
- 15 Install filter assembly onto the end of MAF sensor, secure with OEM clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.

Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**Note: WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.

Installation does require some mechanical skills.

