



Recommended filter cleaning interval every 3000 miles

Part# **Secret Weapon Intake 307-168**

US Patent# **US 7,263,961B2**

Application: **2005-09 DODGE MAGNUM 5.7IL / 2005-09 CHRYSLER 300 5.7L
2005-09 DODGE CHARGER 6.1L**

Parts List: **1 x 4" Weapon*R Air Filter / 1 x Weapon*R Aluminum [Air Intake](#) Tube / 1 x 3.5"-4" Silicon Coupler
1 x 3.5"- 3.5" Silicon Couplers / 1 X 15MM / 4 x Hose Clamps / 1 x grommet**

- 1 Loosen hose clamps securing OEM intake hose. Unplug and remove Air Temp Sensor, put aside for later steps. Remove OEM intake hose.
- 2 Remove nut securing OEM air box, save for later steps . Disconnect rubber PCV hose from side of air box. Pull air box upwards to remove.
- 3 Insert grommet into hole on Weapon*R intake pipe. Unplug AIT Sensor from harness, and insert sensor into grommet on intake pipe. Install 3.5" side of 3.5"-3.5" Weapon*R coupler over throttle body and secure with supplied clamp.
- 4 Insert Weapon*R intake pipe into 3.5" side of the coupler on the throttle body, AIT sensor closest to the throttle body. Secure loosely with supplied clamps. Reconnect wire harness to AIT sensor. Connect OEM PCV hose to Weapon*R intake pipe.
- 6 Insert Weapon*R filter into 4" end of 3.5"-4" coupler. Secure with supplied clamp. Attach filter and coupler assembly to intake pipe, opposite of the end with the grommet. Secure with supplied clamp.
- 7 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances. Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened. Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new Air / Fuel Ratio curves to increased air intake to the engine. Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable) Perform a final inspection before driving vehicle.

Installation of your New Weapon*R Performance Intake System is completed, we hope you enjoy our performance products.

