



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon Intake : 307-169 (NSWP)**

Application : **2005-2007 COBALT 2.0L SUPERCHARGED**

Parts List : 2 x Weapon*R Intake pipe. / 1 x Weapon*R 3" Air Filter / 1 x 15mm x 12" Hose

3 x 3"- 3" Coupler / 1 x Intake System Bracket kit / 6 x 3" Clamp /

- 1 Loosen clamps securing OEM air cleaner tube
- 2 Disconnect and remove the PVC hose from OEM intake and engine.
- 3 Disconnect MAF sensor harness from OEM tube , remove MAF sensor
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box.
- 5 Remove OEM air cleaner box from fender well.
- 6 Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert #1 long Weapon*R intake pipe into the 3" end of the coupler, secure with clamp.
- 8 Measure the OEM PCV hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 9 Install 3"-3" coupler onto tube, 3" side to pipe.
- 10 Install #2 small WR pipe onto end of coupler from under the fender well of vehicle
- 11 Install 3"-3" coupler onto end of #2 small WR pipe
- 12 Install Secret Weapon air filter onto the 3" side of coupler, secure with supplied clamp.
- 13 Install U-shaped bracket on #2 WR pipe to bolt location on inner fender well
- 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 16 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

