



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **SECRET WEAPON INTAKE: 307-170**

US Patent# US 7,263,961B2

Application : **2005-09 FORD MUSTANG GT**

**Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 4" / 1 x 10mm x 24" Hose
2 x 3.5"-4" Coupler / 1 x Intake System Bracket kit / 3 x 4" Clamp**

- 1 Using a 8mm wrench disconnect the negative battery cable and set aside.
- 2 Pull red locking tab outward from the MAF
- 3 Depress tab located on MAF harness and remove then set aside.
- 4 Remove the 10mm bolt securing OEM air cleaner box to fender wall.
- 5 Loosen the clamp securing the inlet tube to the throttle body.
- 6 Remove the tabbed PCV hose from OEM intake and engine and set aside.
- 7 Remove the OEM intake system as one piece.
- 8 Now using a torx screwdriver remove the 2 screws securing the MAF to the OEM inlet.
- 9 Using the same screws attach the MAF to the WR Pipe (ATTENTION TO FLOW DIRECTION)
- 10 Attach the 4" side of the 3.5" - 4" coupler onto the throttle body and use OEM clamp to tighten.
- 11 Insert the WR pipe into the coupler and secure it by using the supplied clamp.
- 12 Now attach the 3.5" - 4" coupler to the new SW Filter and secure it with supplied clamp.
- 13 Slide the remaining clamp over the coupler and slide coupler over the WR pipe.
- 14 Before tightening the clamp Insert the Bracket between coupler and clamp.
- 15 Attach bracket to closest mounting point using the supplied rubber stop as the base point then the bracket to that so it will be secure against vibration.
- 16 Re-attach the MAF Harness to the MAF located on the WR Pipe and secure locking red tab.
- 17 Attach the supplied silicon hose to the vent point located on the valve cover to the new WR pipe.
- 18 Check all clamps to make sure they are tightend against leaks.
- 19 Check for clearance, making sure no parts are interfering with other parts of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Reconnect negative batter cable.
- 22 Start vehicle and let idle for at least 15 min
- IT IS VERY IMPORTANT "DO NOT" REV THE ENGINE DURING THIS PERIOD!!**
- 23 After the settle time you may drive your vehicle.