



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Secret Weapon Intake : 307-176**

**US Patent# US 7,263,961B2**

Application : **2007-2008 Ford Taurus 3.0L V6**

**Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter](#) / 1 x 15mm x 12" Hose / 1 x 10mm x 12" hose  
1 x 3"-3" Coupler / 1 x 2.5"-3" coupler/ 1 x Intake System Bracket kit / 4 x 3" clamp**

- 1 Remove the 9mm emissions line from OEM tube, Disconnect the plastic EVAP hardline from OEM intake pipe.
- 2 Loosen the OEM airbox and rubber intake tube, disconnect the MAF sensor harness from OEM airbox
- 3 Carefully remove the MAF sensor from the OEM airbox, remove the rubber intake tube and OEM airbox
- 4 Place the 2.5"- 3" coupler onto the throttle body and secure with the OEM clamp.
- 5 Place Weapon\*R Intake Tube into the 3" end of the coupler and secure with clamp.
- 7 Install the 9mm hose onto the 9mm port on intake pipe and the plastic EVAP hardline on the engine .
- 8 Install the MAF sensor onto the Weapon-R intake pipe, secure with OEM screws, reconnect harness.
- 9 Insert the Weapon\*R filter into the intake pipe, secure with clamp.

**10 Note: Secret Weapon Filter Option :**

- 11 Install 3"- 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.

19 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**NOTE: Only some early models used a MAF sensor. Disregard MAF info if not applicable to your vehicle.**

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

