



Part# 601-122 SECRET WEAPON TRUCK INTAKE

US Patent# US 7,263,961B2

Application: 1997-00 DAKOTA 5.2L : 1998-02 DAKOTA 5.9L
1998-00 DURANGO 5.2L : 2000-02 DURANGO 5.9L

Parts List: 1 x 4" Weapon*R Air Filter / 1 x Weapon*R Aluminum [Air Intake Tube](#) / 1 x 3.5"-4" Coupler / 3"-3.5" Coupler
1 x 3.5" couplers / 4 x 4" Hose Clamps / 1 x Heat Shield Kit / 1 x Rubber Mounting Grommet, 3 x Black air box screws

- 1 Loosen clamp on air intake plenum and airbox, remove rubber intake tube.
- 2 Remove Airbox, by pulling upwards on airbox assembly.
- 3 **Vehicles with Cruise Control unit in front of OEM Airbox** : Remove and Change factory cruise control unit bracket to supplied cruise control bracket, remount in factory location.
- 4 Remove factory airbox mounting studs from fender, replace with rubber mounting grommets.
- 5 Assemble heat shield by aligning holes #1 to #1 and so on, secure with screws in kit.
- 6 Place the heat shield in the area of the OEM airbox with the intake pipe inlet facing to the rear.
- 7 Secure the heat shield to the bottom of rubber mounting grommet on fender, secure with washer and nut in kit.
- 8 Secure the front tab of heat shield to chassis with bolt.
- 9 Install rubber trim guard onto the round intake tube inlet on heat shield.
- 10 Install the 3.5" coupler onto the Air intake plenum, secure with clamp.
- 11 Insert the intake tube into the 3.5" coupler on air intake plenum, secure with clamp.
- 12 Line up the intake pipe with the top of the rubber grommet on fender, secure with washer and nut in kit.
- 13 Install the 3.5" end of the 3.5"-4" coupler onto the intake tube, secure with clamp.
- 14 Install the Weapon*R Air Filter into the 4" end of the 3.5"-4" coupler, secure with clamp.
- 15 Position air intake pipe for clearance in engine compartment, making sure no parts are touching the vehicle.
- 16 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 17 Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened.
- 18 Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new
- 19 Air / Fuel Ratio curves to increased air intake to the engine.
- 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (**If Applicable**)
- 21 Perform a final inspection before driving vehicle.
- 22 Installation of your New Weapon*R Performance Intake System is completed.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

NOTE: Recommended Air Filter Cleaning Intervals: 3000 Miles.

Please check the contents of this package immediately.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

