



Part# 601-131 SECRET WEAPON TRUCK INTAKE

US Patent# US 7,263,961B2

Application: 2002-03 LIBERTY 3.7L V6

Parts List: 1 x 3" Weapon*R Air Filter / 1 x Weapon*R [Air Intake Tube](#) / 2 x 3" Coupler
4 x 3" Hose Clamps / 1 x Heat Shield Kit / 1 x Rubber Mounting Grommet / 2 x 15mm x 12" hose, 5 x Black airbox screws

- 1 Loosen both hose clamps holding the OEM intake tube, remove OEM intake tube.
- 2 Remove OEM air cleaner box by pulling upwards on box.
- 3 Loosen clamp on resonator box to throttle body.
- 4 Disconnect and remove breather hose connected to resonator box.
- 5 Loosen the 2 bolts on each side of the resonator box, remove resonator box.
- 6 Wipe throttle body clean of grease or dirt , install 1st 3" coupler onto throttle body, secure with clamp.
- 7 Assemble heat shield by aligning holes #1 to #1 and so on, secure with screws in kit.
- 8 Install heatshield in OEM airbox area, secure to chassis with washer, bolt and nut supplied in kit.
- 9 Secure the heatshield tab onto the fan shroud support with supplied washer and bolt.
- 10 Install the intake pipe into the 3" coupler on throttlebody, secure with clamp.
- 11 Measure length from intake pipe to breather port with the 15mm hose supplied in kit, cut to length.
- 12 Install 15mm breather hose onto intake pipe and breather port.
- 13 With remainder of 15mm hose, connect to 2nd breather port on intake pipe and OEM breather port.
- 14 Install 2nd 3" coupler onto end of intake pipe, secure with clamps.
- 15 Install the provided rubber mounting grommet onto heatshield.
- 16 Slide bracket on intake onto rubber mounting grommet, secure intake pipe with supplied washer and nut.
- 17 Install the Weapon*R Air Filter into the other end of 3" coupler, secure with clamp.
- 18 Position air intake pipe for clearance in engine compartment, making sure no parts are touching the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened.
- 21 Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new Air / Fuel Ratio curves to increased air intake to the engine.
- 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (**If Applicable**)
- 23 Perform a final inspection before driving vehicle, Installation is complete.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.
Recommended Air Filter Cleaning Intervals: 3000 Miles.

NOTE: Please check the contents of this package immediately.
Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

