



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 601-149**

US Patent# US 7,263,961B2

Application : **2007-08 FORD EDGE 3.5L V6 / LINCOLN MKX 3.5L V6**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter 3" / 1 x 15mm x 12" Hose/ 1 x 9mm 12" Hose  
2 x 3"- 3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp

- 1 Remove bolts securing OEM air intake, and tube loosen clamps on OEM rubber intake pipe.
- 2 Remove 15mm PCV hose from from OEM intake and engine.
- 3 Remove 9mm line from side of OEM intake pipe
- 4 Remove the OEM rubber intake tube.
- 5 Unplug mass air sensor, and Remove OEM airbox lid with mass air sensor attached
- 6 Unbolt mass air sensor from top of OEM airbox, put aside.
- 7 Remove rest of OEM airbox
- 8 Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with OEM clamp.
- 9 Install the WR intake tube into 3" side of coupler and clamp down
- 10 Take MAF sensor and bolt into Weapon-R plate adapter on intake tube and screw down
- 11 Install 3"-3" to mass air unit and clamp down , then install 3" side of coupler to end of WR intake pipe.
- 12 Measure the OEM PVC hose, replace with supplied 15mm hose, install from PCV port to intake pipe.
- 13 Replace OEM 9mm line to intake pipe , or use (mm hose supplied and replace complete line
- 14 Install 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the end of Weapon\*R pipe, secure with OEM clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

