



Part# 601-169-101 SECRET WEAPON TRUCK INTAKE

US Patent# US 7,263,961B2

Application: 2008 TUNDRA V8

Parts List: 1 x 4" Weapon*R Tall Air Filter / 1 x Weapon*R [Air Intake Tube](#) / 2 x 3.5" - 3.5" Coupler / 1 X Casted 3.5" Elbow
1 x 3.5"-4" Coupler/ 6 x 4" Hose Clamps / 1 x Rubber Mounting Grommet / 1 x 15mm x 16" hose
1 x 4mm x 15" hose

- 1 Disconnect MAF sensor harness, remove MAF sensor from OEM intake pipe for later installation.
- 2 Remove the 2 bolts holding the engine cover, remove engine cover.
- 3 Remove the hoses connected to the OEM air resonator box.
- 4 Mark all hose locations for later hose replacement to new intake tube.
- 5 Loosen hose clamp on intake pipe on throttlebody.
- 6 Loosen the 3 bolts holding the OEM air cleaner box, remove air cleaner box and intake pipe together.
- 7 Wipe throttlebody clean of grease or dirt, install 3.5"-3.5" " coupler onto throttlebody, secure with clamp.
- 8 Insert 3.5" casted elbow into the 3.5" coupler, secure with clamp.
- 9 Install 3.5'-3.5'" coupler onto end of casted elbow, secure with clamp.
- 10 Install intake pipe into end of 3.5" coupler, with vacume ports facing the motor. Secure with clamp
- 11 Install 3.5"-4" " coupler onto end of intake pipe, secure with clamp.
- 12 Install MAF sensor into intake pipe, secure with supplied hex screws.
- 13 Measure the OEM 15mm hose from the OEM port to the intake pipe, cut to length and install onto port on pipe.
- 14 Measure the OEM 4mm hose from the OEM ports to the intake pipe, cut to length and install onto ports on pipe.
- 15 Install the Weapon*R Air Filter into the other end of 3.5"-4" coupler, secure with clamp.
- 16 Line up bracket on intake pipe to hole on chassis, install rubber mounting grommet on chassis.
- 17 Slide bracket onto rubber mounting grommet, secure with washer and nut in kit.
- 18 Position air intake pipe for clearance in engine compartment, making sure no parts are touching the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened.
- 21 Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new
- 22 Air / Fuel Ratio curves to increased air intake to the engine.
- 23 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)
- 34 Perform a final inspection before driving vehicle, Installation is complete.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Please check the contents of this package immediately.

NOTE: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

