



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s Hyper Intake : 901-140 / Dragon Intake : 801-140

Application : 2001- 2005 Honda Civic EX / HX / LX / DX

(2001- 2004 Honda Civic EX / HX / LX / DX #D-489-2 ONLY) exclude GX coupe models

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter](#) / 1 x 15mm x 12" Hose / 1 x 3" coupler

1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp / 1 x 3" thin aluminum elbow, 1 x black AIT grommet  
Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV hose from from OEM intake and engine.
- 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 4 Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 5 Install 3" casted elbow onto 2.5"-3" coupler , install the 3" coupler onto elbow, secure with clamps.
- 6 Insert Weapon\*R intake pipe into the 3" coupler on casted elbow, secure with clamp.
- 7 Measure the OEM PVC hose, replace with supplied 15mm hose, install from PVC port to intake pipe.
- 8 Install the hoses from their point of origin and onto the Weapon \*R intake pipe.
- 9 Install AIT sensor into black grommet in Aluminum elbow.
- 10 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 11 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 12 Install U-shaped part of intake system bracket under the clamp on air filter.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 14 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 15 Secure with washer and nut included in bracket kit.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 18 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

