



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake: 901-141 / Dragon Intake: 801-141**

Application : **2002-05 ACURA RSX TYPE S**

(2002-2004 RSX TYPE-S #D-489-2 ONLY)

Part # 's **Hyper Intake: 901-143 / Dragon Intake: 801-143**

Application : **2002-05 ACURA RSX**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 15mm x 8" Hose / 1 x 10mm x 12" hose /
1 x 2.75"-3" Coupler / 1 x 3"-3" Coupler / 1 x Intake System Bracket kit / 1 x Stainless Steel Clamp

Note: Additional Parts needed when you have a dragon filter. 1 x 2.5-3" Silicon Adapter Hose / 2 x Stainless Steel Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Carefully disconnect the AIT sensor harness on the OEM rubber intake pipe, remove AIT sensor.
- 3 Remove the coolant transfer / 15mm PCV hardline from from OEM intake and engine.
- 4 Remove the 10mm air recirculator hose on OEM intake pipe,
- 5 Mark the coolant tranfer hose origins, install the 10mm hose supplied in kit to those 2 locations.
- 6 Remove the OEM ruber intake tube, remove the OEM air cleaner box by pulling upwards.
- 7 Wipe the throttlebody clean of any grease, install the 2.75" coupler onto throttlebody, secure with OEM clamp.
- 8 Insert the Weapon*R intake pipe into the 3" sideof the coupler and secure with clamp.
- 9 Measure and cut to length the 15mm PVC hose removed, from valve cover port and to Weapon*R intake pipe,
- 10 Install the 10mm hose onto the Air recirculator port on engine and to the Weapon *R intake pipe.
- 11 Insert the Weapon*R filter into the intake pipe, secure with clamp.
- 12 Instal lthe 3"-3" Coupler onto the Weapon*R intake pipe, secure with OEM clamp.
- 13 Install Dragon air filter into coupler, secure with supplied clamp.
- 14 Install U-shaped part of intake system bracket under the clamp on air filter.
- 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 17 Secure with washer and nut included in bracket kit.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. **(If Applicable)**

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

