



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 901-155 / Dragon Intake : 801-155**

Application : **2002-2003 ACURA MDX**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 10mm x 36" Hose
1 x 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp/ 1 x "T" fitting

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the stock crank case vent tube from oem intake tube.
- 3 Disconnect the idle air bypass control valve from stock intake tube.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease or dirt, install the 3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert the intake pipe into 3" coupler on throttlebody, secure with supplied clamp.
- 7 Install the 10mm silicone hose onto the Weapon *R intake pipe, and reconnect to PCV port on motor.
- 8 Reconnect idle air bypass valve to WR tube using other 10mm silicone vacume line.
- 9 If you have 3rd vacume port use "T" fitting to adapt it to the 10mm line.

Note: Secret Weapon Filter Option .

- 10 Install 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 11 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 12 Install U-shaped part of intake system bracket under the clamp on air filter.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 14 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 15 Secure with washer and nut included in bracket kit.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

