



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 901-156 / Dragon Intake : 801-156**

Application : **2005-2007 ACCORD 4CYL WITH HITACHI SENSOR**

**CARB # D-489 (excluding SULEV / LEV2 2003 & 2004 engine families
3HNXV02.4KCP & 4HNXV02.4KCV)**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 15mm x 8" Hose / 1 x 10mm x 12" hose
1 x 1" x 1" hose / 1 x 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" clamp / 2 x 1" Clamps

Note: Additional Parts needed when you have a Dragon Filter, 1 x 2.75"=3" Coupler / 2 x 3" Clamp

- 1 Remove the CCV emissions box from OEM tube, Disconnect the plastic EVAP hardline from OEM intake pipe.
- 2 Loosen the OEM airbox and rubber intake tube, disconnect the MAF sensor harness from OEM airbox
- 3 Carefully remove the MAF sensor from the OEM airbox, remove the rubber intake tube and OEM airbox
- 4 Place the 3" coupler onto the throttle body and secure with the OEM clamp.
- 5 Place Weapon*R Intake Tube into the 3" end of the coupler and secure with clamp.
- 6 Install 1" hose onto 1" port on pipe, insert the CCV box into the 1" hose, secure with supplied clamps.
- 7 Install the 8mm hose onto the 8mm port on intake pipe and the plastic EVAP hardline on the engine .
- 8 Install the MAF sensor onto the Weapon-R intake pipe, secure with OEM screws, reconnect harness.
- 9 Insert the Weapon*R filter into the intake pipe, secure with clamp.
- 10 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 11 Install 2.75"- 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

NOTE: Only some early models used a MAF sensor. Disregard MAF info if not applicable to your vehicle.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

