



ARB # D-489

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's Hyper Intake : 901-161 / Dragon Intake : 801-161

Application : 1999-2005 Odyssey V6

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 2 x 10mm x 36" Hose
1 x 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp/ 1 X "T" Fitting

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the stock crank case vent tube from oem intake tube.
- 3 Disconnect the idle air bypass control valve from stock intake tube.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease or dirt, install the 3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert the intake pipe into 3" coupler on throttlebody, secure with supplied clamp.
- 7 Install the 10mm silicone hose onto the Weapon *R intake pipe, and reconnect to PCV port on motor.
- 8 Vehicles with extra 10 mm port use "T" fitting to connect to remaining ports
- 9 Reconnect idle air bypass valve to WR tube using other 10mm silicone vacume line.
- 10 Install the Weapon*R Hyper filter onto the end of the intake pipe.
Note: Dragon Filter Option : Disregard installation on Hyper filter.
- 11 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Note: Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

