



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's Hyper Intake : 902-117 / Dragon Intake : 802-117

Application : 1993-98 Mazda MX6 V6

Part # 's Hyper Intake : 902-111 / Dragon Intake : 802-111

Application : 1993-98 Mazda MX3 V6

Part # 's Hyper Intake : 902-115 / Dragon Intake : 802-115

Application : 1990-92 Mazda RX7

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter 3" / 1 x 10mm x 6" Hose

1 x 2.5"- 3" Coupler / 1 x 3"-3.5" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp

**Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamps**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove AIT Sensor from OEM air cleaner box.
- 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 4 Wipe the MAF clean of any grease, install the 2.5"-3" coupler onto MAF, secure with OEM clamp.
- 5 Insert Weapon\*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 6 Install the 10mm hose onto the intake pipe, insert the AIT sensor into the hose, reconnect harness.
- 7 Install the Weapon\*R Hyper filter onto the end of the intake pipe.

**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**

- 8 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 9 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 10 Install U-shaped part of intake system bracket under the clamp on air filter.
- 11 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 12 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 13 Secure with washer and nut included in bracket kit.
- 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 16 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

