



CARB PENDING

Recommended filter cleaning every 3000 miles

Part # 's **Hyper Intake : 907-118 / Dragon Intake : 807-118**

Application : **1996-98 Ford Probe 4Cyl**

Part # 's **Hyper Intake : 902-116 / Dragon Intake : 802-116**

Application : **1996-98 Mazda 626 / MX6 4Cyl**

Parts List : 1 x Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 2.5-3" Coupler / 1 x 10mm x 12" Hose / 1 x 15mm x 6" hose
1 x 4mm x 12" hose / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x AFM-TY Adapter Kit/1 x 3"-3" coupler

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove PCV & 4mm Vacuum hose from OEM intake and engine.
 - 3 Disconnect the MAF & AIT sensor harness, carefully remove MAF & AIT sensor from OEM airbox,
 - 4 Loosen the nuts holding the MAF to the OEM airbox, remove the MAF from the airbox.
 - 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
 - 7 Insert Weapon*R intake pipe into the 2.5"-3" coupler, secure with clamp.
 - 8 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 9 Install the 15mm hose onto intake pipe, insert the AIT sensor into the 15mm hose, connect harness.
 - 10 Install the 4mm hose onto the intake pipe, install the 4mm hose onto the 4mm port on engine.
 - 11 Install the 2.5"-3" coupler onto the end of the intake pipe, secure with a clamp.
 - 12 Install MAF sensor into the 2.5"-3" coupler, reconnect MAF sensor harness.
 - 13 Line up the 4 holes on the MAF Sensor to the AFM-TY adapter plate, install the adapter plate onto the MAF.
 - 14 Install the Weapon*R Hyper filter onto the end of the AFM adapter plate.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 15 Install the 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 16 Install filter assembly onto the end of AFM adapter plate., secure with OEM clamp.
 - 17 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 18 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 19 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 20 Secure with washer and nut included in bracket kit.
 - 21 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 22 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 23 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

