



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 902-120 / Dragon Intake : 802-120**

Application : **1999-04 Mazda Protégé 1.8L / 2.0L DOHC**

**Parts List : 1 x Intake pipe. / 1 x Weapon\*R Air Filter 3" / 1 x 10mm x 12" Hose / 1 x 2.5-3" Coupler  
1 x 3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x AIT Grommet**

**Note: Additional Parts needed when you have a Dragon Filter, 1 x 3" Coupler / 2 x 3" Clamps**

1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.

2 Remove PCV hose from OEM intake and engine.

3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,

4 Loosen the nuts holding the MAF to the OEM airbox, remove the MAF from the airbox.

5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.

**Note: If your vehicle has an AIT sensor then use provided grommet and add 1/2 hole in WR pipe right after MAF!  
Insert AIT sensor into grommet and reconnect wire harness.**

6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.

7 Insert Weapon\*R intake pipe into the 2.5"-3" coupler, secure with clamp.

8 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.

9 Install the 3" coupler onto the end of the intake pipe, secure with a clamp.

10 Install MAF sensor into the 3" coupler, reconnect MAF sensor harness.

11 Install the Weapon\*R Hyper filter onto the end of the AFM sensor.

**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**

12 Install the 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.

13 Install filter assembly onto the end of AFM sensor, secure with OEM clamp.

14 Install U-shaped part of intake system bracket under the clamp on air filter.

15 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.

16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.

17 Secure with washer and nut included in bracket kit.

18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.

19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.

20 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

**Note:** Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

