



**CARB PENDING**

Recommended Air Filter cleaning Intervals: 3000 Miles

Part #'s **Hyper Intake : 903-113 / Dragon Intake : 803-113**

Application : **2000-05 Mitsubishi Eclipse 4cyl & V6**

Part #'s **Hyper Intake : 903-117 / Dragon Intake : 803-117**

Application : **1999-03 Mitsubishi Galant 4cyl & V6**

**Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter 4" / 1 x 10mm x 12" Hose/ 1 x 4"-4" coupler  
1 x 2.75"- 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp / 1 x MAF adapter AFM-MT**

**Note: Additional Parts needed when you have a Dragon Filter, 1 x 3" Coupler / 2 x 3" Clamps**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon\*R intake pipe into the 3" coupler, secure with clamp.
- 7 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 8 Line up the holes on MAF to the AFM-MT adapter plate, secure with nuts and bolts in kit.
- 9 Install the Weapon\*R Hyper filter onto the end of the intake pipe.
- 10 Install MAF sensor into Weapon\*R intake pipe, reconnect MAF sensor harness.  
**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 11 Install the 3" coupler onto intake pipe, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

