



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 904-111 / Dragon Intake : 804-111**

Application : **1990-00 Sentra / Sentra SE-R / 1991-02 Infinity G20 / 1995-98 200SX 1.6L / 2.0L
(1990- 2000 SENTRA 1.6L #D-489-2 ONLY)**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 3" coupler/ 3 x 9 mm silicone hose
1 x 4mm silicone hose / 1 x 2.5"- 3" Coupler / 1 x [Intake Bracket kit](#) / 3 x 3" Clamp / 1 x AFM-NS Adapter plate
Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the 15mm PCV and 10mm Air recirculator hoses from OEM intake.
- 3 Unplug and remove the MAF sensor from the air intake system.
- 4 Unplug AIT harness and remove the AIT sensor from OEM airbox.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the coupler, secure with clamp.
- 8 Install the WR 9mm hose on to pcv port and WR intake pipe .
- 9 install other WR 9 mm hose on to Air recirculator valve and then to WR intake pipe
- 10 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 11 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
- 12 Drill out the the 9mm templated hole on the WR MAF adapter to install the AIT sensor into the WR MAF adapter plate.
- 13 Line up the holes on MAF to the AFM-NS adapter plate, secure with nuts and bolts in kit.
- 14 Install the AIT sensor into the MAF adapter plate.
- 15 Install the Weapon*R Hyper filter onto AFM adapter plate..
Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
- 16 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 17 Install filter assembly onto the AFM adapter plate, secure with OEM clamp.
- 18 Install U-shaped part of intake system bracket under the clamp on air filter.
- 19 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 20 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 21 Secure with washer and nut included in bracket kit.
- 22 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 23 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 24 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

