



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 904-119 / Dragon Intake : 804-119**

Application : **2001-2006 Sentra 1.8L**

Parts List : 1 x Intake pipe. / 1 x Air Filter / 1 x 3" coupler / 1 x 4mm x 12" hose / 1 x 10mm x 12" hose
1 x 2.5"- 3" Coupler / 1 x [Intake Bracket kit](#) / 3 x 3" Clamp / 1 x AFM-NS Adapter plate

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV 10mm Air recirculator hoses from OEM intake.
- 3 Remove the 4mm hose from the air resonator box on OEM intake pipe.
- 4 Unplug and remove the MAF sensor from the air intake system.
- 5 Unplug AIT harness and remove the AIT sensor from OEM airbox.
- 6 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 7 Install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 8 Insert Weapon*R intake pipe into the coupler, secure with clamp.
- 9 Install the supplied 10mm hose onto the intake pipe and to the air recirculator valve.
- 10 Install the supplied 4mm hose onto the intake pipe and to the air resonator box.
- 11 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 12 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
- 13 Drill out the 10mm templated hole on the MAF adapter to install the AIT sensor into the adapter.
- 14 Line up the holes on MAF to the AFM-NS adapter plate, secure with nuts and bolts in kit.
- 15 Install the AIT sensor into the MAF adapter plate.
- 16 Install the Weapon*R Hyper filter onto AFM adapter plate..
- 17 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 18 Install filter assembly onto the AFM adapter plate, secure with OEM clamp.
- 19 Install U-shaped part of intake system bracket under the clamp on air filter.
- 20 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 21 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 22 Secure with washer and nut included in bracket kit.
- 23 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 24 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 25 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

