



Recommended [Air Filter](#) Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 904-120 / Dragon Intake : 804-120**

Application : **2002-2006 Sentra V-Spec 2.5L / 2002-2006 Altima 2.5L**

**( 2004 altima lev2 engine family 4nsxv02.585a excluded from CARB )**

Parts List : 1 x Intake pipe. / 1 x Air Filter / 1 x 3" coupler / 1 x 4mm x 12" hose / 1 x 10mm x 12" hose  
1 x 2.5"- 3" Coupler / 1 x Intake Bracket kit / 3 x 3" Clamp / 1 x AFM-NS Adapter plate, 1 x 4mm vacume cap

**Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV 10mm Air recirculator hoses from OEM intake.
- 3 Remove the 4mm hose from the OEM intake pipe.
- 4 Unplug and remove the MAF sensor from the air intake system.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon\*R intake pipe into the coupler, secure with clamp.
- 8 Install the supplied 10mm hose onto the intake pipe and to the PCV port on valve cover
- 9 Reinstall the 4mm hose onto the intake pipe.(or use vacume cap to cap off)
- 10 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 11 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
- 12 Line up the holes on MAF to the AFM-NS adapter plate, secure with nuts and bolts in kit.
- 13 Install the Weapon\*R Hyper filter onto AFM adapter plate..
- 14 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**  
Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the AFM adapter plate, secure with OEM clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon\*R CARB Sticker on a visible place in engine compartment. **( If Applicable )**

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

