



**CARB# PENDING**

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 904-124 / Dragon Intake : 804-124**

Application : **1990-97 Nissan Truck 2.4L / 1998-04 FRONTIER / XTERRA 4 CYL. ONLY**

Parts List : 1 x Intake pipe. / 1 x Air Filter / 2 x 3" coupler / 2 x 3" Clamp/ 1 x AIT Grommet

**Note: Additional Parts needed when you have a Dragon Filter 2 x 3" Clamp**

- 1 Loosen the clamps on the air cleaner assembly. Remove the air cleaner hose.
- 2 Remove the 2 butterfly nuts ontop of the Air cleaner assembly, remove the air cleaner top.
- 3 Remove the air resonator box from fender well.
- 4 Remove the OEM hoses on the lower air cleaner assembly , remove the lower air cleaner assembly.
- 5 Remove the round rubber gasket on the lower air cleaner assembly.
- 6 Install the round rubber gasket onto the Weapon\*R aluminum airbox.
- 7 Install the Weapon\*R aluminum airbox onto the throttle body, tighten the airbox down with OEM butterfly nuts.
- 8 Re-Install the OEM hoses onto the Weapon\*R airbox.
- 9 Install the 3" couper onto the 3" tube on the Weapon\*R airbox.
- 10 Install the Weapon\*R intake pipe into the 3" coupler, secure with supplied clamps.
- 11 Install the Weapon\*R filter onto end of intake pipe.

**12 SPECIAL NOTE: Leave AIT sensor in OEM resonator hose.**

**Or use AIT grommet and drill 5/8 inch hole towards filter end and use grommet for AIT sensor (Pictured #D)**

**Note: Dragon Filter Option :**

- 12 Install 3" coupler onto Dragon air filter, secure with supplied clamp.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 14 Slide the Mounting bracket welded on the intake pipe onto the rubber mounting grommet.
- 15 Secure the bracket to the rubber mounting grommet with supplied hardware.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 18 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.

**Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.**

