



CARB# D-489-1

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 904-128 / Dragon Intake : 804-128**

Application : **2001 Maxima V6**

Parts List : 2 x Intake pipe. / 1 x Air Filter / 2 x 3" coupler / 1 x 4mm x 12" hose / 1 x 10mm x 12" hose/ Blank AFM Plate
1 x 15mm x 12" hose / 1 x 2.5"- 3" Coupler / 1 x [Intake Bracket kit](#) / 3 x 3" Clamp/ 1 x pipe with grommet

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove the 15mm PCV and 10mm Air recirculator hoses from OEM intake.
 - 3 Remove the 4mm hose from the air resonator box on OEM intake pipe.
 - 4 Unplug and remove the MAF sensor from the air intake system.
 - 5 Unplug AIT harness and remove the AIT sensor from OEM airbox.
 - 6 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 7 Install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
 - 8 Insert Weapon*R intake pipe into the coupler, secure with clamp.
 - 9 Install the supplied 15mm hose onto the intake pipe and to the PCV valve on valvecover.
 - 10 Install the supplied 10mm hose onto the intake pipe and to the air recirculator valve.
 - 11 Install the supplied 4mm hose onto the intake pipe and to the air resonator box.
 - 12 Install the 3" coupler onto end of intake pipe, secure with clamp.
 - 13 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
 - 14 Line up the holes on MAF to the AFM-Blank adapter plate, secure with nuts and bolts in kit.
 - 15 Install 3"-3" coupler onto MAF plate clamp down, and install WR tube with AIT grommet.
 - 16 Re-install AIT sensor into grommet and plug harness into AIT sensor.
 - 17 Install the Weapon*R Hyper filter onto AFM adapter plate..
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 18 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 19 Install filter assembly onto the WR intake pipe, secure with OEM clamp.
 - 20 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 21 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 22 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 23 Secure with washer and nut included in bracket kit.
 - 24 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 25 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 26 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

