



ARB # D-489-1

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 905-111 / Dragon Intake : 805-111**

Application : **1990-97 TOYOTA COROLLA**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter 3](#) / 1 x 10mm x 12" Hose  
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp

**Note: Additional Parts needed when you have a Dragon Filter.**

1 x 3"-3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 4 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 5 Insert Weapon\*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 6 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.  
**Note: For 92-97 Corolla which may not have PCV port, use the port on the WR pipe with a 5" piece of hose Vacuum hose to install the AIT onto the Vacuum port.**
- 7 Install the Weapon\*R Hyper filter onto the end of the intake pipe.  
**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 8 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 9 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 10 Install U-shaped part of intake system bracket under the clamp on air filter.
- 11 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 12 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 13 Secure with washer and nut included in bracket kit.
- 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 16 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

