



CARB # D-489-1

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Dragon Intake : 805-121**    **Hyper Intake: 905-121**

Application : **2000-05 TOYOTA CELICA GT / GTS**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter](#) 3" / 1 x 10mm x 12" Hose/ 1 x 2.75"-2.75" coupler  
1 x 2.5" -3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp / 1 x 4mm Vacuum Cap

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
  - 2 Unbolt the Air Recirculator valve, move aside for later re-installation.
  - 3 Remove PCV and all 4mm vacuum hoses from OEM intake and engine.
  - 4 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
  - 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
  - 6 Install MAF sensor into Weapon\*R intake pipe, reconnect MAF sensor harness.
  - 7 Wipe the throttlebody clean of any grease, install the 2.5" -3" coupler onto throttlebody, secure with OEM clamp.
  - 8 Insert Weapon\*R intake pipe into the 3" coupler, secure with clamp.
  - 9 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
  - 10 Install the 4mm vacuum cap onto the 4mm port on the intake manifold, left behind by the OEM 4mm hoses.
- PICTURE BELOW SHOWS REPRESENTATION ON HOW INTAKE GOES TOGETHER**
- 11 Install air recirculator valve onto bracket on intake pipe with OEM screw.
  - 12 Install the Weapon\*R filter onto the end of the intake pipe.
  - 13 Stretch the 3"-3" coupler onto the intake pipe, secure with clamp.
  - 14 Insert the Dragon or Secret Weapon air filter into the coupler, secure with supplied clamp.
  - 15 Install U-shaped part of intake system bracket under the clamp on air filter.
  - 16 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
  - 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
  - 18 Secure with washer and nut included in bracket kit.
  - 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
  - 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
  - 21 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

