



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s Hyper Intake : 905-140 / Dragon Intake : 805-140

CARB # D-489-2

Application : 1994-96 Toyota Camry / Lexus ES300 V6

LEXUS ES300 only

Parts List : 1 x Weapon\*R Intake pipe. 1 x Weapon\*R [Air Filter](#) 3" / 1 x 10mm x 12" Hose / 1 x 15mm x 12" Hose  
1 x Intake System Bracket kit / 5 x 3" Clamp / 3 x 3" Coupler

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV & Air Recirculator valve hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Loosen the nuts holding the MAF to the OEM airbox, remove the MAF from the airbox.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon\*R intake pipe into the 3" coupler, secure with clamp.
- 8 Measure the OEM PVC hose, replace with supplied 15mm hoses, install from PVC ports to intake pipe.
- 9 Install the 10mm hose onto the air recirculator valve and onto the Weapon\*R intake pipe.
- 10 Install the 3" coupler onto the end of the intake pipe, secure with a clamp.
- 11 Install MAF sensor into the 3" coupler, reconnect MAF sensor harness, secure with clamp.
- 12 Install the Weapon\*R Hyper filter onto the end of the AFM adapter plate.  
**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 13 Install the 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 14 Install filter assembly onto the end of AFM., secure with OEM clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



1994 Camry V6 DOHC 24V Secret Weapon intake install picture