

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s Hyper Intake: 905-142 / Dragon Intake: 805-142

Application: 2003-08 TOYOTA COROLLA

(2002-2003 COROLLA / 2002-2004 MATRIX #D-489-2 ONLY)

Parts List: 1 x Weapon\*R Intake pipe. /1 x Weapon\*R Air Filter 3" /1 x 10mm x 12" Hose

1 x 2.75" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp

## Note: Additional Parts needed when you have a Dragon Filter, 1 x 2.75"-3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.75" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon\*R intake pipe into the 2.75" coupler, secure with clamp.
- 7 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 8 Install the Weapon\*R Hyper filter onto the end of the intake pipe.
- 9 Install MAF sensor into Weapon\*R intake pipe, reconnect MAF sensor harness.

## Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.

- 10 Install the 3" end of the 2.75"-3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 11 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 12 Install U-shaped part of intake system bracket under the clamp on air filter.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 14 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 15 Secure with washer and nut included in bracket kit.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 18 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

## WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. INSTALLED PRODUCTS ARE NON-REFUNDABLE!

Note: Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



