



CARB # D-489-1

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 905-144 / Dragon Intake : 805-144**

Application : **2002-06 Toyota Camry 4Cyl (04 model CARB restricted)**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter 3"](#) / 1 x 10mm x 12" Hose/ 1 x 15mm x 12" hose
/ 1 x 2.75"-2.75" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp

Note: Additional Parts needed when you have a Dragon Filter, 1 x2.75"- 3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove PCV hose from OEM intake and engine.
 - 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
 - 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 5 Wipe the throttlebody clean of any grease, install the 2.75"-2.75" coupler onto throttlebody, secure with OEM clamp.
 - 6 Insert Weapon*R intake pipe into the 2.5"-3" coupler, secure with clamp.
 - 7 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 8 Insert the 15mm hose into the 15mm port on pipe, Insert the Air recirculator valve port into on pipe.
 - 9 Install the Weapon*R Hyper filter onto the end of the intake pipe.
 - 10 Install MAF sensor into Weapon*R intake pipe, reconnect MAF sensor harness.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 11 Install the 2.75"-3" coupler onto intake pipe, secure with supplied clamp.
 - 12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
 - 13 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 16 Secure with washer and nut included in bracket kit.
 - 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

