



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 905-149 / Dragon Intake : 805-149**

Application : **2003-06 Scion XA**

**( 2004 XB #D-489-2 ONLY)**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter](#) 3" / 1 x 15mm x 24" Hose  
1 x 2"-2.5" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp

**Note: Additional Parts needed when you have a Dragon Filter.**

**1 x 2.5"-3" Coupler / 2 x 3" Clamps**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine valvelover.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove the air recirculator valve from the airbox.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 2"- 2.5" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon\*R intake pipe into the 2.5" coupler, secure with clamp.
- 8 The intake will be placed behind the drivers side headlight in the fenderwell.**
- 9 Measure the OEM PVC hose, replace with supplied 15mm hose, install from PVC port to intake pipe.
- 10 Install the Weapon\*R Hyper filter onto the end of the intake pipe.
- 11 Install MAF sensor into Weapon\*R intake pipe, reconnect MAF sensor harness.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 12 Install the 2.5" end of the 2.5"-3" coupler onto intake pipe, secure with supplied clamp.
- 13 Install filter assembly onto the end of Weapon\*R intake pipe, secure with clamp.
- 14 Install the rubber mounting grommet to the closest hole to the bracket on intake pipe.
- 15 Line up the bracket on the intake pipe to the rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon\*R CARB Sticker on a visible place in engine compartment. **( If Applicable )**

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

**Note:** Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

