



CARB # D-489-1

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 905-151 / Dragon Intake : 805-151**

Application : **2002-2004 TOYOTA CAMRY / SOLARA V6**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 8" Hose
1 x 3"-3" silicone coupler/ 1X 15MM 12" Hose / 1 x [Intake System Bracket kit](#)/ 1x Plastic "T" fitting

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3" Coupler / 2 x 3" Clamps

- 1 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
 - 2 Disconnect the OEM 4mm lines from top of OEM airbox and put aside for later use.
 - 3 Remove air recirculator valve & hose from OEM intake and engine.
 - 4 Remove bolts securing OEM air cleaner box,remove OEM air intake box.
 - 5 Place 3"-3" coupler over the throttle body and clamp down.
 - 6 Insert WR intake tube into 3" side of reducer and clamp down.
 - 7 Install 15mm hose from pipe to valve cover pcv port.
 - 8 Using Plastic "T" fitting reconnect the 3x 4mm lines all together . (see pic 1 below)
 - 9 Install the 10mm hose onto the air recirculator valve and onto the Weapon*R intake pipe.
 - 10 Install the Weapon*R Hyper filter onto the end of the intake pipe.
 - 11 Install MAF sensor into Weapon*R intake pipe, reconnect MAF sensor harness.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 12 Install the 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 13 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
 - 14 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 17 Secure with washer and nut included in bracket kit.
 - 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

