

Part # 's **Dragon Intake: 806-117**

Application : **2005-07 Subaru Forester / Impreza / Outback NT**

**Parts List :** 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter / 2 x 10mm x 24" Hose / 1 x 2.75" coupler  
1 x Intake System Bracket kit / 1 x 2.75"-3" Coupler / 5 x 3" Clamp / 1 x Grommet/ 1 x "T" Fitting

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV hoses from OEM intake and engine.
- 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 4 Remove MAF sensor from factory air box, install onto Weapon\*R intake pipe with supplied hardware.
- 5 Wipe the throttlebody clean of any grease, install the 2.75" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon\*R intake pipe into the 2.75" coupler, secure with clamp.  
Use vacume cap to cap off port on pipe closest to filter end of tube. **DO NOT USE THIS PORT FOR VACUME**
- 7 Measure from valve cover PCV port to intake pipe port. Replace with supplied 10mm hoses.
- 8 Use "T" fitting to crankcase PCV port to 10mm port on intake pipe. Replace with supplied 10mm hose.  
**Note: Later models may have an AIT sensor. Drill a 3/8" hole at least 3" from throttlebody,**
- 9 **insert supplied grommet, and insert AIT sensor into grommet.**  
Install the Weapon\*R Hyper filter onto end of intake pipe.
- 10 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 11 Stretch the 2.75-3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the Weapon\*R Intake Pipe, secure with clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( **If Applicable** )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

