

Part #'s **Hyper Intake : 907-111 / Dragon Intake : 807-111**

Application : **1996-03 Chevy Cavalier / Pontiac Sunfire / 96-01 Pontiac Grand Am 2.4L
98-03 Malibu 2.4L / 90-95 Grand am 2.3L /**

Parts List : **1 x Weapon®R Intake pipe. / 1 x Weapon®R Air Filter 3" / 1 x 10mm x 6" Hose
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp, 2 x 3"-3" Coupler / 2 x 3" Clamps**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the AIT sensor from the OEM air cleaner box.
- 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 4 Install the 2.5"-3" coupler onto the air resonator box, secure with OEM clamp.
- 5 Insert Weapon®R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 6 Install the 10mm hose onto the intake pipe, insert the AIT sensor into the 10mm hose.
- 7 Install the Weapon®R Hyper filter onto the end of the intake pipe.

Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.

- 8 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 9 Install filter assembly onto the end of Weapon®R intake pipe, secure with OEM clamp.
- 10 Install U-shaped part of intake system bracket under the clamp on air filter.
- 11 Install the rubber mounting grommet to the closest hole to the Weapon®R air filter.
- 12 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 13 Secure with washer and nut included in bracket kit.
- 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 16 Place Weapon®R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon®R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



Dragon intake install picture



Intake with enclosed aluminum air box installed.