



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 907-113 / Dragon Intake : 807-113**

Application : **1998-02 Chevy Cavalier / Pontiac Sunfire 2.2L (Non Ecotec)**

Parts List : 2pcs Weapon*R Intake pipes. / 1 x Weapon*R Air Filter 3" / 1 x black rubber grommet / 1 x 3" Coupler
1 x 10mm x 12" hose / 1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamps

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the AIT sensor from the OEM air cleaner box.
- 3 Remove the PVC hose from the valve cover and the OEM intake hose.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Install the 2.5"-3" coupler onto the throttlebody, secure with OEM clamp.
- 6 Insert the 90 degree Weapon*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 7 Insert the AIT sensor into the black rubber grommet.
- 8 Install the 3" coupler onto the 90 degree intake pipe, secure with clamp.
- 9 Install the 2nd intake tube into the 3" coupler, secure with clamp.
- 10 Install the 10mm hose onto the PVC port on the valvecover, then to the port on the intake pipe.
- 11 Install the Weapon*R Hyper filter onto the end of the intake pipe.

Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.

- 12 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 13 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 14 Install U-shaped part of intake system bracket under the clamp on air filter.
- 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 17 Secure with washer and nut included in bracket kit.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

