



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 907-140 / Dragon Intake : 807-140**

Application : **1995-00 Dodge Avenger V6 / Chrysler Sebring 2.5L V6**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 10mm x 24" Hose
1 x 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp**

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV hose from OEM intake and engine.
- 3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 4 Wipe the throttlebody clean of any grease, install the 3" coupler onto throttlebody, secure with OEM clamp.
- 5 Insert Weapon*R intake pipe into the 3" coupler, secure with clamp.
- 6 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 7 Install the hoses from their point of origin and onto the Weapon *R intake pipe.
- 8 Install the Weapon*R Hyper filter onto the end of the intake pipe.
Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
- 9 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 10 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 11 Install U-shaped part of intake system bracket under the clamp on air filter.
- 12 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 13 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 14 Secure with washer and nut included in bracket kit.
- 15 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 16 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 17 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

