



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 907-142 / Dragon Intake : 807-142**

Application : **2000-04 Dodge Neon 2.0L NON TURBO**

Parts List : 2 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 12" Hose
3 x 2.5"-3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp/ 1x black rubber grommet

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove PCV hose from OEM intake and engine.
 - 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
 - 4 Remove AIT sensor from OEM airbox and disconnect from wire harness and put aside.
 - 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
 - 7 Insert 1st Weapon*R intake pipe into the 2.5"-3" coupler, secure with clamp.
 - 8 Install the 2.5"-3" coupler onto end of intake pipe, secure with clamp.
 - 9 Install the MAF sensor into the 2.5"-3" coupler, secure with clamp.
 - 10 Install the 2.5"-3" coupler onto the other end of the MAF sensor.
 - 11 Install the 2nd Weapon*R pipe into the end of the 2.5"-3", clamp down.
 - 12 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 13 Install the grommet into bottom of WR pipe, and Insert AIT sensor into grommet and reconnect wire harness to AIT.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 14 Install the 3"-3" coupler onto intake pipe, secure with supplied clamp.
 - 15 Install filter assembly onto the end of MAF sensor, secure with OEM clamp.
 - 16 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 19 Secure with washer and nut included in bracket kit.
 - 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

