



CARB PENDING

Recommended Air Filter cleaning intervals:3000 Miles.

Part # 's **Dragon Intake : 807-144**

Application : **2003-05 Dodge Neon SRT-4**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 12" Hose / 1 x 3"-3" Coupler / 1 x 2.5-3" Coupler/1 x Intake System Bracket kit /4 x 3" Clamp/ 1x black rubber grommet/1 x 10mm vacume cap**
Additional: 3"X3" Coupler & 3" clamp for dragon filter

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Remove AIT sensor from OEM airbox and disconnect from wire harness and put aside.
- 4 Remove and put aside the check valve bracket.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the Turbo clean of any grease, install the 2.5"-3" coupler onto Turbo inlet, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the 2.5"-3" coupler, secure with clamp.
- 8 Bolt down WR pipe to OEM 10mm location on valve cover. (pic #1)
- 9 Install check valve bracket to WR pipe bracket and bolt down. (pic #2)
- 10 Install boost vacume solenoid hose to WR small intake port on tube(pic#3)
- 11 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 12 Install the grommet into bottom of WR pipe, and Insert AIT sensor into grommet and reconnect wire harness to AIT.

Note: Secret Weapon Filter Option

- 13 Install the 3"-3" coupler onto intake pipe, secure with supplied clamp.
- 14 Install filter assembly onto the end of MAF sensor, secure with OEM clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Note: Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

PIC#1

PIC#2



Dragon intake kit show above.



PIC#3

Secret Weapon intake kit install with Shield optional upgrade.
(Aluminum air shield comes with SW intake kit only)