



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 907-146 / Dragon Intake : 807-146**

Application : **2002 CAVALIER / SUNFIRE 2.2L (ECOTEC ONLY)**

Parts List : 1 x Intake pipe. / 1 x Weapon*R Air Filter 3" / 1x 2.75-3" Coupler/ 1 X 2.75"-2.75" Coupler
1 x Intake System Bracket kit / 2 x 3" Clamp

Note: Additional Parts needed when you have a Dragon Filter 2 x 3" Clamps

1. Unbolt the screws holding down the Oem airbox top
2. Disconnect the clamp from the Oem intake tube to the top part of that Oem airbox, remove top Oem airbox(pic#2)
3. Disconnect the clamp from end of Oem intake tube from black box, and remove Oem intake tube (pic #3)
4. Unclamp the 2 clamps on each end of the OEM intake tube and remove stock OEM intake tube.
5. Unbolt the 10mm hold down bolts that are located in the bottom of the Oem airbox, remove bottom air box
6. Install 2.75" coupler to end of Oem box that sits ontop of throttle body, and clamp coupler down
7. Install WR intake tube into other end of 2.75" coupler and clamp down.
8. Install 2.75"-3" reducer onto pipe, 2.75" side needs to be stretched onto WR intake tube , and clamp down
9. Install WR filter into 3" or reducer and clamp down

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

