



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 907-149 / Dragon Intake : 807-149**

Application : **1994-1996 BERETTA 3.1L**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 12" Hose
2 x 3"-3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp/ 1 x Grommet**

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"- 3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon*R intake pipe into the 3"-3" coupler, secure with clamp.
- 7 Vehicles with no MAF install 3"-3" coupler onto end of intake pipe, secure with clamp.
- 8 Vehicles MAF sensor install the 3"-3" coupler, secure with clamp.
- 9 Install the MAF into the 3"-3" coupler clamp down
- 10 Vehicles with AIT sensors must drill 3/4" hole in side of tube for sensor grommet. Insert AIT into grommet.
- 11 Install the Weapon*R Hyper filter onto the end of the MAF reconnect MAF sensor harness.
- 12 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 13 Install the 3"-3" coupler onto WR filter , secure with supplied clamp.
- 14 Install filter assembly onto the end of MAF sensor, secure with OEM clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

