



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 907-150 / Dragon Intake : 807-150**

Application : **2001-03 STRATUS V6**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 10mm x 12" Hose
1 x 3"-3.5" Coupler / 1 x 2.5"-3" coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp
1 x AIT Grommet / 1 x Cast elbow

Note: Additional Parts needed when you have a Dragon Filter, 2 x 3"-3" Coupler / 2 x 3" Clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Remove PCV hose from OEM intake and engine.
 - 3 Unplug AIT sensor from OEM plastic elbow, and remove carefully AIT sensor from elbow. Put aside.
 - 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 5 Wipe the throttlebody clean of any grease, install the 3.5"-3" coupler onto throttlebody, secure with OEM clamp.
 - 6 Install WR Cast elbow into 3" side of coupler and clamp down.
 - 7 Insert 3"-3" coupler onto end of WR Cast elbow and clamp down.
 - 8 Insert Weapon*R intake pipe into the end of 3" coupler and clamp down.
 - 9 Install the Weapon*R Hyper filter onto the end of the intake pipe.
 - 10 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 11 Reinsert AIT sensor into grommet that is in WR cast elbow. Plug AIT sensor harness into AIT sensor
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 12 **Install 3"-3" coupler onto end of WR pipe and clamp down, then install WR filter onto end of 3" coupler.**
 - 13 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 16 Secure with washer and nut included in bracket kit.
 - 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

