



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Dragon Intake: 807-165 Hyper Intake: 907-165**

Application : **2002- 2004 Grand Am 2.2L (ECOTEC ONLY)**

Parts List : 1 x Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 2.75-3" Coupler/ 1 X 2.75"-2.75" Coupler
1 x Intake System Bracket kit / 4 x 3" Clamp

Dragon intake requires additional 3"X3" coupler & 3" clamps

1. Unbolt the screws holding down the Oem airbox top
2. Disconnect the clamp from the Oem intake tube to the top part of that Oem airbox, remove top Oem airbox
3. Disconnect the AIT sensor located in the OEM tube. Remove AIT sensor from OEM tube and put aside.
4. Disconnect the clamp from end of Oem intake tube from black box, and remove Oem intake tube
5. Unclamp the 2 clamps on each end of the OEM intake tube and remove stock OEM intake tube.
6. Unbolt the 10mm hold down bolts that are located in the bottom of the Oem airbox, remove bottom air box
7. Install 2.75" coupler to end of Oem box that sits on top of throttle body, and clamp coupler down
8. Install WR intake tube into other end of 2.75" coupler and clamp down.
9. Install 2.75"-3" reducer onto pipe, 2.75" side needs to be stretched onto WR intake tube , and clamp down
10. Install WR filter into 3" or reducer and clamp down
11. Reinstall AIT sensor into WR grommet in WR pipe. Connect AIT sensor harness.

