



## CARB PENDING

Recommended filter cleaning interval every 3000 miles

Part #'s **Secret Weapon Intake : 807-174**

Application : **2006-07 PONTIAC SOLSTICE 2.4L Ecotec / 2007 SATURN SKY 2.4L Ecotec**

**Parts List : 2 x Weapon\*R Intake pipe. / 1 x Weapon\*R 3" Air Filter / 1 x 10mm x 12" Hose / 1 X 2.5"-3" COUPLER  
3 x 3"- 3" Coupler / 1 X ALUMINUM ELBOW/ 1 x Intake System Bracket kit / 8 x 3" Clamp / 1 x 1" clamp**

- 1 Loosen clamps securing OEM air cleaner tube
- 2 Disconnect and remove the PVC hose from OEM intake and engine.
- 3 Disconnect MAF sensor harness from OEM tube , remove MAF sensor from OEM intake tube
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box.
- 5 Remove OEM air cleaner from front of vehicle
- 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with clamp.
- 7 Insert Aluminum elbow into 3" side of the coupler.
- 8 Install 3"-3" coupler to aluminum elbow and clamp down
- 9 Install MAF sensor into small WR pipe and secure
- 10 Install small WR pipe into 3" coupler and clamp down
- 11 Measure the OEM PCV hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 12 Install 3"-3" coupler onto tube, 3" side to pipe.
- 13 Line up holes on Long WR pipe with frame of vehicle and use OEM grommet locations
- 14 Install #2 Long WR pipe onto end of coupler and clamp down
- 15 Install 3"-3" coupler onto end of #2 Long pipe
- 16 Install Secret Weapon air filter onto the 3" side of coupler, secure with supplied clamp.
- 17 Reconnect MAF wire harness to sensor installed in pipe.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

